



# MyChangan Smartphone Application

# CONTENTS

- 1. Introduction.....2
- 2. Application download.....2
- 3. Account creation.....3
- 4. Vehicle binding.....4
- 5. Account login.....5
- 6. Homepage overview.....7
- 7. Vehicle control passcode.....8
- 8. Vehicle management.....10
- 9. Vehicle status.....11
- 10. Connection status.....12
- 11. Vehicle controls.....13
- 12. Battery management.....21
- 13. Vehicle sharing.....22
- 14. Vehicle software upgrade.....23
- 15. User manual.....24
- 16. Schedule a trip.....25
- 17. Scan and message center.....26
- 18. Personal centre.....27
- 19. Vehicle unbinding.....28

# 1. INTRODUCTION

The MyChangan smartphone Application is an integrated digital companion designed to enhance your ownership experience beyond the vehicle itself.

Provided as an additional feature with your Changan vehicle, the App brings together intelligent connectivity, remote functionality, and essential vehicle information—all in one intuitive platform.

Through the MyChangan App, you can securely connect to your vehicle, monitor key vehicle data, manage settings, and access a wide range of smart features designed to support everyday driving, journey planning, and vehicle care.

From real-time vehicle status and battery management to remote controls, vehicle software updates, and digital documentation, the App is built to give you greater visibility, convenience, and control.

This booklet will guide you through each feature step by step, helping you get the most from the MyChangan app and your vehicle's connected technology.

Whether you're setting up your account for the first time or exploring advanced functions, you'll find everything you need to stay informed, connected, and confidently in control.

# 2. APPLICATION DOWNLOAD



Here is how the 'MyChangan' App will appear in the Apple App Store or Google Play Store

1

Search '**MyChangan**' in the Apple App Store or the Google Play Store. Alternatively, scan the below QR codes

2

Download the App




Apple App store-  
IOS



Google Play Store-  
Android



### 3. ACCOUNT CREATION






1 Click **Register Now**

2 Select the correct **purchase region** for the vehicle. Then input your **Email Address**. This must be the same email address that your Dealership registered your vehicle sale with. Create a password and accept the **User Agreement**. Then click **Register Now**

3 The App will then show **Registration Success** and will confirm your account name. Then, click **Login**

4 After clicking **Login**, your account will login automatically, Then click **Bind Vehicle** to begin the vehicle binding process

# 4. VEHICLE BINDING



1 Login then click **Bind Vehicle**




2 Check vehicle information then click **Confirm to bind**

3 \*If the vehicle purchase Information cannot be found, please contact your selling Changan dealership who must register your vehicle ownership on the appropriate portal

4 After the vehicle bind is successful, it will then go to the application homepage

# 5. ACCOUNT LOGIN

LOGIN WITH YOUR EMAIL ADDRESS AND PASSWORD






1 Click **Password Login**

2 Select the correct **Country/Region**, input the Email address and password for your account

3 Select to agree to the **Privacy Policy and User Agreement**, then **Login**

# 5. ACCOUNT LOGIN

LOGIN WITH YOUR EMAIL ADDRESS AND A ONE TIME PASSCODE




1 Click **Verification Code Login**

2 Select the correct **Country/Region**, input your account email then accept the **Privacy Policy** and **User Agreement** and click **Send Code**

3 Input the **One Time Passcode** received to your email address, it will then login automatically


## 6. HOMEPAGE OVERVIEW



- 1 Shows your current vehicle name and allows you to click into vehicle management
- 2 Opens your camera to login into your vehicle's infotainment screen
- 3 Message center
- 4 Personal center
- 5 Remaining range
- 6 Bluetooth connection status for Bluetooth key
- 7 Latest update time
- 8 Vehicle status: Parked, In-Use, Charging
- 9 Shows door and boot status, click to check the vehicle's status update
- 10 Vehicle control
- 11 Current connection type, Network or Bluetooth
- 12 Air conditioning control with interior temperature and heated seating controls (if applicable)
- 13 Battery management and battery remaining percentage
- 14 Schedule a trip
- 15 Vehicle sharing
- 16 Schedule OTA upgrade
- 17 User manual

# 7. VEHICLE CONTROL PASSCODE

## HOW TO CREATE A VEHICLE CONTROL PASSCODE



Setup your own personal 6-digit vehicle Control Passcode to control your vehicle. This Passcode will be required when you are controlling the vehicle using the remote control function. When controlling the vehicle through the Bluetooth pathway, the passcode will not be required.


- 1 Click **Personal Center** on the Application homepage  Or click your **vehicle name** on the Application homepage 
- 2 Click **My Vehicle** and select the vehicle required
- 3 Click **Vehicle control passcode**
- 4 Click **Vehicle control passcode again**
  - Click **Send verification code** to get a One Time Passcode to your account email then click **Next**
  - **Input the One Time Passcode** received to email
  - **Create and input your chosen 6-digit passcode in both boxes** then click **complete**
- 5 Click **Validity Period**

Setup a validity period of your Passcode. Once set, the App will not require a Passcode when you send any command to the vehicle within the below selected timeframes :


  - 30 minutes
  - 8 Hours
  - 3 Days
  - 7 Days

# 7. VEHICLE CONTROL PASSCODE


## HOW TO CHANGE A VEHICLE CONTROL PASSCODE




The vehicle control passcode can be changed by following the same steps used to create the initial code.

- 1 Click **Personal Center** on the Application homepage  Or click your **vehicle name** on the Application homepage 
- 2 Click **My Vehicle** and **select the vehicle**
- 3 Click **Vehicle control passcode**
- 4 Click **Vehicle control passcode again**
  - Click **Send verification code** to get a One Time Passcode to your account email then click **Next**
  - **Input the One Time Passcode** received to email
  - **input your new 6-digit passcode in both boxes** then click **complete**


# 8. VEHICLE MANAGEMENT



1 Click **Vehicle name** to go to Vehicle management





2 Click the vehicle to edit the information




3 Edit vehicle information including the vehicle nickname and registration number.

# 9. VEHICLE STATUS



- 1 Touch vehicle image to go to the vehicle status page
- The system will show the latest vehicle status updated :
- 1. Door status Open-Close
  - 2. Door lock status Lock-Unlock
  - 3. Windows status Open-Close
  - 4. Boot status Open-Close
  - 5. Light status Open-Close
  - 6. Tyre pressure status
  - 7. Other status
- \* The vehicle status list may differentiate between each model

# 10. CONNECTION STATUS




There are 2 connection types that can be used in the app:

- 1 **Network connection**
  - Click the **network connection** icon
  - App features and vehicle control features can be used
  - You cannot put the car in ready mode unless the physical key is in the vehicle
  - Your passcode will be required to use the vehicle controls
  - The windows will open <10% for cooling when using the 'window open' vehicle control button
- 2 **Bluetooth connection**
  - Click the **Bluetooth connection** icon
  - App features and vehicle control features can be used
  - You can put the car in ready mode without the physical key being in the vehicle
  - Your passcode will not be required to use the vehicle controls
  - The windows will open fully when using the 'window open' vehicle control button

# 11. VEHICLE CONTROLS

## DOORS


### Door unlock



1 Click  to unlock the door



2 Input your 6-digit Vehicle Control Passcode

### Door lock



1 Click  to lock the door


2 Input your 6-digit Vehicle Control Passcode



# 11. VEHICLE CONTROLS


## WINDOWS

### Open window



1 Click  to open the window

### Close window



1 Click  to close the window


-  Window closed
-  Window opened

\*When the vehicle is being operated through the Bluetooth connection, the windows will open fully. When the vehicle is being operated through the Network connection, the windows will open < 10% for cooling only.

# 11. VEHICLE CONTROLS


## BOOT

### Open boot



1 Click  to open the boot

### Close boot




1 Click  to close the boot

-  boot closed
-  boot opened

# 11. VEHICLE CONTROLS


## HORN AND LIGHTS

### Use horn and lights



1 Click  to execute horn and light


### Use lights



1 Scroll along your vehicle control buttons and click  to flash the vehicle lights for 10 seconds



# 11. VEHICLE CONTROLS

## AIR CONDITIONING



There are 2 ways to turn on/off your air conditioning :

- 1 Click  to turn on or off the air conditioning. The button will turn blue when the air conditioning is turned on.
- 2 Go to the air conditioning page by clicking on the temperature tab, click the **A/C** tab then adjust to the desired temperature and click **Turn on A/C**
- 3 Click to start **Windscreen Defog**




\* After remote A/C is turned on, it will automatically turn off after 15 minutes.

\*\* Detail of operation may differ between each model.

# 11. VEHICLE CONTROLS

## SEAT VENTILATION



### How to turn on and off seat ventilation

- 1 Select the **temperature** tab, click the **Seats** tab at the top of the App screen, then click the **ventilation icons** on the seat that needs to be turned on

The icon colour will turn blue when the function is turned on


The first click will turn on level 3 of seat ventilation

The second click will turn on level 2 of seat ventilation

The third click will turn on level 1 of seat ventilation

Click again to turn off the seat ventilation

To summarize, you can adjust the ventilation level as well as control the on/off switch of this function by clicking the **ventilation icon** multiple times.





\* After remote A/C is turned on, it will automatically turn off after 15 minutes.

\*\* Detail of operation may differentiate between each model.

# 11. VEHICLE CONTROLS

## SEAT HEATING




### How to turn on and off seat heating

- 1 Select the **temperature** tab, click the **Seats** tab at the top of the app screen, then click the **heat icons** on the seat that needs to be turned on

The Icon colour will turn red when the function is turned on

The first click will turn on level 3 of seat heating  
The second click will turn on level 2 of seat heating  
The third click will turn on level 1 of seat heating  
Click again to turn off the seat heating

To summarize, the user can adjust the gear level as well as control the on/off switch of this function by clicking the **heating icon** multiple times.




\* After remote A/C is turned on, it will automatically turn off after 15 minutes.

\*\* Detail of operation may differentiate between each model.

# 11. VEHICLE CONTROLS


## STEERING WHEEL HEATING




### How to turn on/off steering wheel heating

- 1 Select the **temperature** tab, click the **Seats** tab at the top of the App screen, then click the **steering wheel heating icon**

The icon colour will turn red when the function is on.





Steering wheel heating is on



Steering wheel heating is off

- 2 Click **Turn off** to turn off all enabled functions in this seats page

# 12. BATTERY MANAGEMENT



## 1 Shows the charging status and battery percentage on the application homepage

1. Charging status (charging or not charging)

2. Remaining battery\*

\*The estimated remaining battery percentage will depend on driving behaviour

## 2 Charging limit

To view and set a charging limit for your vehicle, select the **battery** tab on the Application homepage.

Adjust the % by moving the toggle to limit or increase the maximum battery charging.

1. Recommended Value for daily use is 80%-90%

2. Recommended Value for longer mileage > 90%

## 3 Scheduled charging




Use this feature to setup a specific period for charging.

If the function is turned on, then the vehicle will not start charging until the start time has been reached.

**1. Start time** : set the start charging time

**2. End time** : set the end charging time. If the end charging time is not defined, then the vehicle will stop charging when the battery percentage limit has been reached.

# 13. VEHICLE SHARING








- 1 Click **Share** on the application homepage to go to Sharing management
- 2 **Sharing management**
  - This will show all current vehicle access that you are sharing with other individuals
  - Click **stop sharing** to stop sharing with your chosen individuals
  - Click **Add share** to share vehicle access with a new individual
  - You can share vehicle access with a maximum of 3 individuals
- 3 **Vehicle Sharing**

Share vehicle access with a new individual

  1. Input the email address of the individual who you want to share vehicle access with
  2. Select the time period (validity period) to confirm how long you wish to share access with this individual
    - 1 Day : share for 1 day
    - 1 Week : share for 1 week
    - Permanent : share permanently
    - Customized : Define your own start-stop sharing period
  3. Click **Send code** to send a One Time Passcode to your email
  4. Enter the One Time Passcode and click **Confirm sharing**
  5. After successful sharing, the individuals who you have shared access with will receive a confirmation email. They can then log into their MyChangan App with their email to operate the car.




Please note that the individual must have created a MyChangan App account first.

# 14. VEHICLE SOFTWARE UPGRADE



- 1 Click **Upgrade** on the application homepage to go to the Vehicle upgrade page
- 2 **Vehicle upgrade**  
Before upgrading the vehicle's software, the user must have finished downloading the whole Over The Air package for the vehicle (please see the vehicle user manual for guidance).  
Show upgrade instructions and detail:
  - Software version
  - Estimated upgrade time
  - Release notesor click **View Upgrade Notes**  
Click **Schedule Upgrade** to setup the upgrade time
- 3 **Vehicle upgrade in progress**  
When the scheduled start time has been reached, the upgrade will begin. The user can check upgrade progress in the App
- 4 The app will show the upgrade results when the upgrade is finished
- 5 If the vehicle is on the latest software the App will advise 'This is the latest software' and will confirm the software version




# 15. USER MANUAL



- 1 Click the **Manual** tab on the Application homepage to go to the Owners manual page
- 2 **User manual**  
Show user manual separated by categories
  - o Preparations before driving
  - o Intelligent riding
  - o Vehicle driving
  - o Charging and discharging
  - o Maintenance and self-service
  - o In case of emergency
  - o Etc.
- 3 **Search**  
You can use the search bar to search for content within the manual by using keywords

# 16. SCHEDULE A TRIP

## BATTERY PRE-HEATING



1 Click **Schedule** on the application home page to go to the **Schedule Trip** page

2 **Scheduled Trip**  
This page shows two battery warm-up schedules that you can set ready for your departure and return times

The battery will be warmed up before your departure time



3 **Repeat**  
If desired, you can set a repeating schedule for your chosen days

Users can set the departure time, set the cycle, and control the switch to setup a schedule that meets their own habits.

\* When the battery warm-up is activated , the vehicle will consume energy from the power battery.

\*\*Battery pre-heating needs to be scheduled and activated at least 1 hour in advance . If the time set for activating battery pre-heating is less than 1 hour, the vehicle will be rescheduled to the next time slot for battery pre-heating.



# 17. SCAN AND MESSAGE CENTER



**1 Scan to login**  
Scan QR Code on vehicle infotainment screen for login and vehicle owner verification

**2 Message center**  
Messages from Changan company

# 18. PERSONAL CENTER





- 1 Account and Security**
  - Change account Email
  - Set and change login password
  - Delete your account
- 2 My Vehicle**
  - Go to Vehicle management page
  - Here you can view vehicle details and set your vehicle passcode
- 3 Settings**
  - Set Application language
  - Setup distance unit (km/miles)
  - Setup tyre pressure unit
  - Setup Permission for the App (Bluetooth, location and camera)
- 4 About us**
  - Contact us
  - User agreement
  - Privacy Policy
  - Application version
- 5 Log out**

Logout Application on this device

# 18. PERSONAL CENTER

## ACCOUNT AND SECURITY





### Account and Security

- 1 Email**
  - Change account Email
  
- 2 Login Password**
  - Edit password for account login
  
- 3 Account Cancellation**
  - Delete current account
  - \* Please unbind all vehicles under the account before deleting
  - \*\* you can create a new account with a deleted account at anytime.

# 18. PERSONAL CENTER

## SETTINGS



### Settings

- 1 Language**
  - you can change application languages in the App
  - Supported are English, German, French, Arabic, Danish, Spanish, Finnish, Italian, Dutch, Norwegian, Portuguese, Russian, Swedish, Chinese languages
- 2 Mileage unit**
  - Setup distance unit as Miles or Kilometer
- 3 Tyre pressure unit**
  - Setup tyre pressure unit as psi, kPa or bar
- 4 System permission**



To assign permission required for mobile application

  - Bluetooth access
  - Location access
  - Camera access

\* If you do not allow permissions, some functions may be inoperative

# 18. PERSONAL CENTER


## ABOUT US




### About us

- 1 Contact us**
  - Contact your Changan call center
- 2 User agreement**
  - Shows all user agreements for the Application
- 3 Privacy policy**
  - Shows the privacy policy for the application
- 4 App version**
  - Shows the version of App
  - click to check and update to a higher version if one is available


# 19. VEHICLE UNBINDING



1 Click the **Vehicle name** to go to Vehicle Management



2 Click on the vehicle that you want to unbind






3 Click **Unbind Vehicle**



4 Check vehicle information then click **Unbind vehicle**

# 19. VEHICLE UNBINDING



5 Click **Confirm** to unbind the vehicle  
*\* You can re-bind to the vehicle after unbinding by following the usual bind process*

6 You will then receive a One Time Verification code to your account email, input this code then click **Next**

7 After being unbound, it will go to **My Vehicle**. If you then want to bind a new vehicle, click **Go to Binding**

Changan UK reserves the right to amend, update, or modify the information contained in this booklet at any time and without prior notice. Please note that the MyChangan Application interface and available functions may vary from the images and descriptions shown in this booklet due to application updates, software enhancements, or differences between vehicle models. As a result, certain features referenced may not be available on all vehicles or across all model variants.